



EN Need help?

Online
Go to www.philips.com/dictation

DE Benötigen Sie Hilfe?

Online
Besuchen Sie www.philips.com/dictation

FR Besoin d'aide ?

En ligne
Visitez notre site www.philips.com/dictation

ES ¿Necesita ayuda?

En línea
Diríjase a www.philips.com/dictation

IT Bisogno di aiuto?

Online
Andare su www.philips.com/dictation

NL Hulp nodig?

Online
Ga naar www.philips.com/dictation

SV Behöver du hjälp?

Online
Gå till www.philips.com/dictation



© 2016 Speech Processing Solutions GmbH. All rights reserved.

Specifications are subject to change without notice. Philips and the Philips shield emblem are registered trademarks of Koninklijke Philips N.V. and are used by Speech Processing Solutions GmbH under license from Koninklijke Philips N.V. All trademarks are the property of their respective owners.

Document version 1.0, 23/06/2016, 7737 003 2010.1

PHILIPS

SpeechMike

Premium Touch

SMP3700/SMP3800



For product information and support, visit
www.philips.com/dictation

EN Quick start guide

DE Kurzanleitung

FR Guide de démarrage rapide

ES Guía de inicio rápido

IT Guida rapida di introduzione

NL Snelle startgids

SV Snabbstartsguide



What's in the box

● Verpackungsinhalt
● Contenido del embalaje
● Wat is meegeleverd

● Contenu de l'emballage
● Contenuto della confezione
● Förpackningens innehåll



- Dictation microphone
- Diktiermikrofon
- Microphone de dictée
- Micrófono de dictado
- Microfono di dettatura
- Dicteermicrofoon
- Dikteringsmikrofon



- USB cable
- USB-Kabel
- Câble USB
- Cable USB
- Cavo USB
- USB-kabel
- USB-kabel



- Hanging bracket
- Halterung
- Crochet
- Soporte de sujeción
- Staffa di supporto
- Ophangsteuntje
- Väggfäste



- Quick start guide
- Kurzanleitung
- Guide de démarrage rapide
- Guía de inicio rápido
- Guida rapida di introduzione
- Snelle startgids
- Snabbstartsguide

Connect

- Anschließen
- Conectar
- Aansluiten
- Connecter
- Collegare
- Anslut

Software

- Software
- Logiciel
- Software
- Software
- Software
- Programvara

Philips SpeechControl software
www.dictation.philips.com/support

Install

- Installation
- Instalación
- Installatie
- Installation
- Installazione
- Installation

Configure

- Konfiguration
- Configuration
- Configuración
- Configurazione
- Configuratie
- Konfiguration

Record

- Enregistrer
- Aufnehmen
- Grabación
- Registrazione
- Opnemen
- Spela in

A Start dictation software

- Diktiersoftware starten
- Lancer le logiciel de dictée
- Iniciar el software de dictado
- Avviare il software di dettatura
- Start dicteersoftware
- Starta dikteringsprogrammet

B Create a recording

- Eine Aufnahme erstellen
- Créer un enregistrement
- Crear una grabación
- Creare una registrazione
- Maak een opname
- Skapa en inspelning

C Stop recording

- Aufnahme beenden
- Arrêter l'enregistrement
- Parar la grabación
- Interrompere la registrazione
- Opname beëindigen
- Stoppa inspelning

D End-of-letter (EOL), priority

- Briefende (EOL), Priorität
- Fin de lettre (EOL), priorité
- Fin-de-carta (EOL), prioridad
- Fine-lettera (EOL), priorità
- Einde-brief (EOL), prioriteit
- End-of-letter (EOL), prioritet

Legend:

- End-of-letter (EOL), priority
- End-of-letter (EOL), prioritet
- Priority

Overview

- Übersicht
- Présentation
- Descripción general
- Panoramica
- Overzicht
- Översikt

Legend:

- Microphone
- Mikrofon
- Micrófono
- Micròfono
- Mikrofoon
- Mikrofon

1

- Microphone
- Mikrofon
- Micrófono
- Micròfono
- Mikrofoon
- Mikrofon

2

- Record indicator light
- Aufnahme-Kontrollleuchte
- Voyant d'enregistrement
- Luz indicadora de grabación
- Indicatore luminoso di registrazione
- Controlelampje opname
- Indikatorlampja inspelning

3

- Instruction
- Anweisung
- Instrucción
- Istruzioni
- Instruktion
- Instructie

4

- End-of-letter (EOL), priority
- Briefende (EOL), Priorität
- Fin de lettre (EOL), priorité
- Fin-de-carta (EOL), prioridad
- Fine-lettera (EOL), priorità
- Einde-brief (EOL), prioriteit
- End-of-letter (EOL), prioritet

5

- Insert/overwrite
- Einfügen/Überschreiben
- Insérer/écraser
- Insertar/sobrescribir
- Inserimento/Sovraregistrazione
- Invoegen/overschrijven
- Lägg till/Skriv över

6

- Rewind
- Rücklauf
- Retour
- Rebobinado
- Riavvolgimento
- Spola tillbaka
- Terug

7

- Record
- Aufnahme
- Enregistrement
- Grabar
- Registrazione
- Opname
- Spela in

8

- Play/pause
- Wiedergabe/Pause
- Lecture/pause
- Reproducir/pausa
- Riproduzione/Pausa
- Afspelen/pauze
- Spela upp/Paus

9

- Fast-forward
- Schneller Vorlauf
- Avance rapide
- Avance rápido
- Avanti veloce
- Snel vooruit
- Snabbspola framåt

10

- Touch navigation/left mouse button
- Touch-Navigation/linke Maustaste
- Navigation tactile/bouton gauche de souris
- Navegación táctil/botón izquierdo del ratón
- Navigazione touch/pulsante sinistro del mouse
- Touchnavigatie/linker muisknop
- Touch-navigering/vänster musknapp

11

- Left mouse button
- Linke Maustaste
- Bouton gauche de souris
- Botón izquierdo del ratón
- Pulsante sinistro del mouse
- Linker muisknop
- Vänster musknapp

12

- Right mouse button
- Rechte Maustaste
- Bouton droit de souris
- Botón derecho del ratón
- Pulsante destro del mouse
- Rechter muisknop
- Höger musknapp

13

- Programmable function keys
- Programmierbare Funktionstasten
- Touches de fonction programmables
- Botones con función programable
- Pulsanti funzione programmabili
- Programmerbare funktietoetsen
- Programmerbara funktionsknappar

14

- Speaker
- Lautsprecher
- Haut-parleur
- Altavoz
- Altoparlante
- Luidspreker
- Högtalare

15

- USB cable
- USB-Kabel
- Câble USB
- Cable USB
- Cavo USB
- USB-kabel

16

- Bar code scanner (SMP3800)
- Barcodeleser (SMP3800)
- Scanner de code-barres (SMP3800)
- Escáner de código de barras (SMP3800)
- Lettores codici a barre (SMP3800)
- Barcodeleser (SMP3800)
- Streckkodsläsare (SMP3800)

17

- Scan button (SMP3800)
- Scantaste (SMP3800)
- Bouton de scan (SMP3800)
- Botón escanear (SMP3800)
- Pulsante di scansione (SMP3800)
- Scanknop (SMP3800)
- Skanningsknapp (SMP3800)

18

- Left mouse button
- Linke Maustaste
- Bouton gauche de souris
- Botón izquierdo del ratón
- Pulsante sinistro del mouse
- Linker muisknop
- Vänster musknapp